

Rehosting FlexNet Embedded licenses

It is possible to move licenses between FlexNet Embedded license servers.

Note: Changes will not apply to the server without synchronization (online server) or upload the license file (online and offline server).

Procedure

1. Go to the Advantest License Portal: <https://license.advantest.com/> and login.
2. Go to the **License Management** tab.
3. In the "Re-host Licenses" section, select **Re-host Licenses**.
4. Select one of the following options (re-host based upon the license server or based upon an entitlement):
 - **By license server** - a list of license servers IDs is displayed
 - **By entitlement** - a list of entitlement IDs is displayed
5. Select a license server or entitlement as appropriate and click **Continue**.
6. Enter the **Re-host count** (number of licenses that you want to re-host) and click **Continue**.
 - Fill all** - enters Re-host count for all available licenses (visible with the filter).
 - Clear all** - reverts the selections to the original values on the initial license server.
7. Review the re-hosting summary.
8. When you are sure that the information has been entered correctly, click **Apply License Count Changes**.

The Download license files page is displayed.
9. If your license server is connected to the internet, synchronization with the back office with **server viewer's synchronization tab**, or perform the command `sync-fne-server` , or wait the **automatic synchronization in every 12-hour**.

If the license server is not connected to the internet, download or email the zip file and upload it with the **server viewer's Offline server update tab** to remove the licenses from the server. After removing the licenses from the server **Download** the confirmation file on the **server viewer's Offline server update tab**. The confirmation file needs to be uploaded to the Advantest Licensing Back-Office to confirm that the licenses have been removed from the server in the next step.

10. If the license server is connected to the internet, close the **Removal Confirmation** dialog box.
If the license server is not connected to the internet, click **Upload** in the **Removal Confirmation** dialog box (if you have closed the **Removal Confirmation** dialog box accidentally, you can do the upload via **Upload Removal Confirmation File (offline server only)** on the **License Management** tab).
11. In order to activate the removed licenses to another license server follow the instruction to [activate licenses](#).

Related information

- [Activating licenses](#)

Revision #11

Created 2025-10-15 09:59:16 CEST by Ekaterina Nikitina

Updated 2026-07-03 10:43:37 CEST by Heike Klein