Rehosting FlexNet Embedded licenses

It is possible to move licenses between FlexNet Embedded license servers.

> Note: Changes will not apply to the server without synchronization (online server) or upload the license file (online and offline server).

Procedure

1. Go to the Advantest License Portal: https://license.advantest.com/ and login.
2. Go to the **License Management** tab.
3. In the "Re-host Licenses" section, select **Re-host Licenses.**
4. Select one of the following options (re-host based upon the license server or based upon an entitlement):
   - **By license server** - a list of license servers IDs is displayed
   - **By entitlement** - a list of entitlement IDs is displayed
5. Select a license server or entitlement as appropriate and click **Continue**.
6. Enter the **Re-host count** (number of licenses that you want to re-host) and click **Continue**.
   Fill all - enters Re-host count for all available licenses (visible with the filter).
   Clear all - reverts the selections to the original values on the initial license server.
7. Review the re-hosting summary.
8. When you are sure that the information has been entered correctly, click **Apply License Count Changes.**
   The Download license files page is displayed.
9. If your license server is connected to the internet, synchronization with the back office with **server viewer's synchronization tab**, or perform the command **`sync-fne-server`**, or wait the **`automatic synchronization in every 12-hour`**.
   If the license server is not connected to the internet, download or email the zip file and upload it with the **server viewer's Offline server update tab** to remove the licenses from the server. After removing the licenses from the server **Download** the confirmation file on the **server viewer's Offline server update tab.** The confirmation file needs to be uploaded to the Advantest Licensing Back-Office to confirm that the licenses have been removed from the server in the next step.

The bin files are only valid for 24 hours. So you need to do the actions within this 24 hours timeframe, otherwise you need to get a new bin file from the appropriate source.

10. If the license server is connected to the internet, you can proceed to step 11.
    If the license server is not connected to the internet, click **Upload** in the **Removal Confirmation** dialog box (if you have closed the **Removal Confirmation** dialog box accidentally, you can do the upload via **Upload Removal Confirmation File (offline server only)** on the **License Management** tab) and upload the file from the FNE server viewer you got in the step before.
11. In order to activate the removed licenses to another license server follow the instruction to activate licenses.

Related information

- Activating licenses

Revision #12
Created 2025-10-15 09:59:16 CEST by Ekaterina Nikitina
Updated 2026-11-19 14:55:29 CET by Heike Klein