

Uninstalling the FNE license client

Uninstalling the FNE license client is done manually using yum.

About this task

There are two options for uninstalling the FNE license client:

- Remove the FNE client only, which results in automatically switching back to using the FNP license client and FNP licensing.
- Completely remove the FNE client installation, which removes the license client, the FNE Server Viewer, and the `test_license_checkout` tool.

Procedures

Uninstalling the FNE license client only

To remove the FNE client only, enter the command:

```
yum remove v93000-fne-client
```

Completely uninstalling the FNE license client and tools

To completely remove the FNE client installation, enter the command:

```
yum remove v93000-fne-client advantest-fne-server-viewer advantest-test_license_checkout
```

Results

FNE license client is no longer installed on the SmarTest system controller.

Revision #1

Created 2025-10-15 09:59:15 CEST by Ekaterina Nikitina

Updated 2025-10-15 09:59:15 CEST by Ekaterina Nikitina